

106

SDRAM

104

FLASH

102

BOOT LOADER

110

108

CPU

100

115

120

Television

FIGURE 1
(PRIOR ART)




FIGURE 2

FIG. 3




Figure 3

400

220

FLASH

BOOT LOADER PROGRAM

222

0x00400000

DEFAULT
APPLICATION
PROGRAM

224

0x00000000




Figure 4

FIG. 5




FIGURE 5

09727193-024204




FIGURE 6

TOP SECRET




Figure 7